
# DISASSEMBLING THE 413 BOX GEAR BOX



the shaft casing onto the center housing and the 413 shaft.

Step 2

Put the bolts aside. You will need them when you reassemble the gear box system

Step 3

Pull out center section and 413 shaft out of housing



Be sure to count the spacers, type and number. You will need to replace these exactly when you reassemble your gear box.

It is a good idea to have extra spacers on hand. Sometimes you need to add them when reassembling your box.

# GB-000413 GEAR BOX PARTS



<u>ITEM #</u> 1	PART# GB-150144	DESCRIPTION Race	
2	GB-150136	Cone Bearing	
3	GB-222083	Shaft	7 Flipped over
4	GB-600445	Key	0 0
5	GB-101030	Gear	0
6	GB-300020	Seal	
7	GB-050211	Сар	0
8	GB-000182	Housing	8
9 10	GB-390195 GB-390021	Gasket.003, Clear, 413 box Gasket.015, White, 413 box	



#### **ASSEMBLING 413 GEAR BOX**



## Step 1

Insert GB-300020 seal into cap GB-050211.



Drop GB-150144 Race into GB-050211 cap. It should seat firmly.—may need to be tapped lightly with hammer.



Step 3

Place GB-600445 key into slot in side of shaft GB-222083.



Step 4

Slide gear GB-101030 onto shaft.



## Step 5

Place one GB-105136 cone bearing on top of gear

Step 6

Place one GB-105136 cone bearing on bottom of shaft

#### ASSEMBLING 413 GEAR BOX

Finished assembly shown ready to insert into 413 gear box housing GB-050211

Insert shaft assembly Step 7 into housing and bolt securely.

Step 8 Insert 215 center section into 413 housing and bolt securely.





### Gear Box Assembly Used on Drive Wheel Units

